

Firmware Version 30.21 ESC/POS

USB Interface or other

Buffer Capacity
4K bytes

Handshaking Operation (busy condition)
Offline or receive buffer full

Resident Character
Alphanumeric

Automatic Line Feed
(CR command function)
Disabled

Print Density
LIGHT [1 2 3] DARK

Maintenance Information

Thermal Head : 1.056 km
Autocutter : 6871 cuts

DIP Switch 1
1 2 3 4 5 6 7 8

■ ■ ■ ■ ■ ■ ■ ■

DIP Switch 2
1 2 3 4 5 6 7 8

■ ■ ■ ■ ■ ■ ■ ■

Select Modes by pressing Feed button.
Continue SELF-TEST: Less than 1 second
Mode Selection : 1 second or more

Mode Selection

Modes

- 0: Exit and Reboot Printer
- 1: NV Graphics Information
- 2: Receipt Enhancement Information
- 3: Customize Value Settings
- 4 or more: None

Select Modes by executing following procedure.

- step 1. Press the Feed button less than 1 second as many times as the selected mode number.
- step 2. Press Feed button for 1 second or more.

Customize Value Settings

Modes

- 0: Exit
- 1: Print Current Settings
- 2: Print Density
- 3: Baud Rate
- 4: Automatic Paper Reduction
- 5: Auto Paper Feed&Cut at cover close
- 6: Paper Width
- 8: Default Character
- 9: Embedded Font Replacement
- 10: Interface Selection
- 11: USB Interface Settings
- 12: Power Supply Output
- 13: Printing Speed
- 14: Other Settings

Select Modes by executing following procedure.

- step 1. Press the Feed button less than 1 second as many times as the selected mode number.
- step 2. Press Feed button for 1 second or more.

11.USB Interface Settings

Modes

0: Return to the previous menu

1: Class

11.USB Interface Settings
11.1.Class

Modes

- 0: Return to the previous menu
-] * 1: Vendor Class
- 2: Printer Class

] means default value.
* means current set value.

11.USB Interface Settings

11.1.Class

Printer Class

Saved. You can turn off the printer.